Shiloh House Allworx Phone Labels:

- 1. Print the finished template.
- 2. Cut out the template by following the inside lines (arcs and notches).
- 3. Remove the line label cover (clear piece) from your 9212 or 9212L phone.
- 4. Place the line label you created into the clear line label cover.
- 5. Snap the cover with the line label installed back into the 9212 or 9212L phone.

