

Shiloh House Allworx Phone Labels:

1. Print the finished template.
2. Cut out the template by following the inside lines (arcs and notches).
3. Remove the line label cover (clear piece) from your 9212 or 9212L phone.
4. Place the line label you created into the clear line label cover.
5. Snap the cover with the line label installed back into the 9212 or 9212L phone.

FRP-SHILOH	FRP-JAC	FRP-OTHER	FRP-CORP	
JAC x103	JAC x103	JAC x103		
Conf Brg *408	Conf Brg *408	Conf Brg *408	Conf Brg *408	
CALL-2	CALL-2	CALL-2	CALL-2	
CALL-1	CALL-1	CALL-1	CALL-1	